

www.unicalighting.com
1-888-89-UNICA

Chas | Instructions

WHO MAUREZ

Caution: Never pull or lift the lamp by the flexible metal arm! ①

Important: Do not connect the lamp to the mains supply until the assembly is complete.

► Adjusting the lamp

Caution: The shade heats up very quickly. Allow it to cool down completely before touching it!

Hold the lamp by the flexible metal arm and adjust the position of the shade with the pin as shown in fig. ②. Bend the metal arm into the required shape.

Important: When positioning the lamp or making adjustments, please make sure that the shade cannot come into direct contact with books, heat-sensitive synthetic materials or combustible surfaces. N.B.: Minimum distance from the nearest lit surface is 30 cm.

► Changing the bulb

Caution: Remove the plug from the socket and allow the lamp to cool down completely. Do not touch the replacement bulb with your bare hands!

Hold the protective glass cover with one hand and use a small screwdriver to loosen one of the four retaining hooks. ③

Carefully detach the glass cover, remove the spent bulb from the socket and fit the replacement. ④

Fit the glass cover into three of the retaining hooks and hold it in position with one hand. Using a screwdriver, push the fourth hook gently back over the edge of the glass and allow it to click into place. ③

► Cleaning

The protective glass cover can be cleaned as required with an ordinary household glass cleaner. Use a damp cloth for the aluminium parts.


► Technical specification

230/125 volts, Halogen 12 volts, 50 watts. GY 6,35 socket. Electronic safety transformer with integrated toggle switch. Cable length 300 cm. Dimmers cannot be used.


 Minimum distance from nearest lit surface 30 cm.

Any repairs that may become necessary must be carried out by a qualified electrician.



①




④



②



③



12

13



www.unicalighting.com
1-888-89-UNICA